

GAS GRILLS

NOTE: FOR OUT DOOR USE ONLY

OPERATING

1. Prior to opening main cylinder valve, and lighting grill, place all control knobs in the CLOSED position. (turn left)
2. Open main cylinder valve. Hold a lit butane gun next to a burner and turn the burner control knob to OPEN. Burning will ignite. The second burner in each section will ignite instantly simply by turning it on.
3. Once burners are lit, adjust temperature.

CLEANING

1. Once finished cooking, turn off all burners. (to the left)
2. Clean grates with non-metallic pads (Scotch Brite) while grates are hot.

NOTE: DO NOT USE A WIRE BRUSH ON STAINLESS STEEL GRATES.