

PROPANE PATIO HEATER

NOTE: FOR OUTDOOR USE ONLY

OPERATING

1. Check and assure the control knob is on "OFF" position.
2. Place gas cylinder inside the Cylinder Base, and securely connect the regulator to the propane gas cylinder.
3. Turn the cylinder valve on. Apply a dishwashing soap (1part) and water (3parts) solution to the connection at the regulator and cylinder. Bubbles will form if the connection is leaking.
4. In case of leaks, turn off the propane cylinder valve, under the leaking connection and check & clean the connection. Reconnect the regular and leak test again.

LIGHTING

1. To light the Pilot, purge the gas line leading to the pilot assembly. Press and turn the control knob "HIGH" position and keep it depressed in for 1 to 2 minutes.
 - a. Press the control knob and turn the "PILOT" position.
 - b. Hold the control knob in and press the ignition button until the pilot lights.
 - c. Keep the control knob depressed for 30 seconds to heat the thermocouple.
 - d. Release the control knob and the pilot should stay lit.

NOTE: TO VISUAL CHECK THE IGNITION OF THE PILOT, SLIDE THE VIEWING HOLD COVER TO EITHER SIDE.

- d. Once the pilot flame stay one, close the viewing hold cover.

SET THE HEAT LEVEL

1. Press and turn the control knob to "HIGH" position, the burner will light immediately.
2. Press and turn the control knob to desired heat level.

CONTINUED...

PROPANE PATIO HEATER

(CONTINUED)

NOTE: WHILE IN USE, THE BURNER FLAME SHOULD BE MAINLY BLUE IN APPEARANCE WITH A SMALL AMOUNT OF YELLOW.

NOTE: SMOKE AND ODOR (NOT GAS ODOR) EMISSION MAY OCCUR IN THE FIRST 15 MINUTES OF USE. RUN HEATER AT HIGH SETTING FOR AT LEAST 15 MINUTES TO ELIMINATE THIS PROBLEM.

STOP

1. Press and turn the control knob to "PILOT" position, the burner will extinguish but the pilot will stay ON.
2. To extinguish the pilot, press and turn the control knob to "OFF" position.
3. Turn off gas supply.
4. Do not attempt to relight the heater for 5 minutes after the LP cylinder valve has been closed.

RESTARTING AFTER SAFETY SHUTDOWN

1. Turn the gas control to "OFF" position.
2. Wait 5 minutes
3. Repeat steps from lighting.